



Нажмите кнопки "POWER" и "SETUP" индикатор горит, введите код пульта дистанционного управления, индикатор гаснет, установка завершена.

"Power+setting" LED lighting, enter the remote control code, lighting off and setting success.

When setting a particular model remote control function after the success, only a few buttons at the remote control available is normal



"Power+Setting" LED lighting, enter the remote control code, lighting off and setting success.

Нажмите кнопку "POWER" и "SETUP" индикатор горит, введите код пульта дистанционного управления, индикатор гаснет, установка завершена.

### PROJECTOR 001-027



### PIONEER 101-122



### JVC 201-205



### SONY 301-319



### PANASONIC 401-408



### TOYOTA 501-502



### ALP 601-602



### REHABILITATION WU 701-706



### OWN-BRAND 901-978

